

SVEN®
YOU WANT – WE CAN

Standard
Wireless Keyboard

USER'S MANUAL



**COMFORT 3300
WIRELESS**

www.sven.fi

Congratulations on your purchase of the Sven Keyboard + Mouse Wireless Combo Set!

Please read this User's Manual before using the unit and retain this User's Manual in a safe place for future reference.

COPYRIGHT

© 2016. SVEN PTE. LTD. Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information in this Manual is given on 'as is' terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this Manual.

UNPACKING

Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.

CONTENTS

1. SPECIAL FEATURES	2
2. PACKAGE CONTENTS	2
3. SYSTEM REQUIREMENTS	2
4. INSTALLATION	2
5. CONNECTION	3
6. TROUBLESHOOTING	4
7. TECHNICAL SPECIFICATIONS	4

Technical support is on www.sven.fi.

1. SPECIAL FEATURES

- Classic fullsize layout
- Waterproof design
- 2.4 GHz USB nano receiver
- Coverage range up to 10 m
- Automatic detection, no need to match the receiver with the pointing device

2. PACKAGE CONTENTS

- Wireless keyboard — 1 pc
- Wireless mouse — 1 pc
- 2.4 GHz USB nano receiver — 1 pc
- AAA batteries — 3 pcs
- User's Manual — 1 pc
- Warranty card — 1 pc

3. SYSTEM REQUIREMENTS

- Windows XP/Vista/7/8/10.
- Free USB port.

4. INSTALLATION

- Open the cover of the mouse battery compartment, insert 2 AAA batteries into the battery compartment matching the polarity, and close the cover of the battery compartment (Fig. 4).
- Open the cover of the battery compartment at the top of the keyboard, insert AAA battery matching the polarity, and close the cover of the battery compartment (see Fig. 4).




Fig. 1




Fig. 2



Please match the polarity when installing the batteries. Incorrect polarity can cause malfunction of the device, which gives no claims for warranty servicing.



It is necessary to always install only the same type of batteries, because installation of different types of batteries with different levels of charging can cause leaking of one of the batteries, which can damage the device.

5. CONNECTION

- Connect the 2.4 GHz USB nano receiver to a free USB port of your PC.
- To activate the set, press any button of the mouse or turn the scroll wheel. If the connection is correct, the set will turn on automatically.
- After finishing your work, you can pull out the receiver from the PC USB port and insert it into the mouse as shown in Fig. 4.
- If the mouse or keyboard don't work, connect them to the nano receiver again. To reconnect the mouse to the nano receiver, press its right button and the scroll wheel at the same time and, while holding them, pull out and insert the 2.4 GHz nano receiver back into the USB port. To reconnect the keyboard to the nano receiver, press its «ESC» and «K» buttons at the same time and, while holding them, pull out and insert the 2.4 GHz nano receiver back into the USB port.

Notes:

- **Do not place the receiver into a confined metal space (table drawer, box, safe), as a metal screen does not transmit radio signals.**
- **If batteries run down, there are «lapses» in operation of the mouse or keyboard. In such a case replace the batteries with new ones.**
- **If there is a long pause in operation of the mouse or keyboard, they enter the Sleep mode. To enter the working mode just press any button.**




Fig. 3. Receiver connection




Fig. 4




Fig. 5

6. TROUBLESHOOTING

Problem	Solution
The keyboard/mouse is not working.	<ol style="list-style-type: none"> 1. Check whether the batteries have been installed correctly. If necessary, replace the batteries with new ones matching the polarity. 2. Pull out the USB receiver and insert it back, make sure that it is not damaged. 3. We recommend that you address your nearest service center.

If none of the above methods can solve the problem, please seek professional advice at your nearest service center. Never attempt to repair the product yourself.

7. TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Q-ty of keyboard keys	104
Q-ty of mouse buttons	2 + 1 (scroll wheel)
Keyboard layout	Rus/Ukr/Eng
OS compatibility	Windows XP/Vista/7/8/10
Interface	USB
Extrapolated mean life	more than 20 000 000 strokes
Coverage range, m	up to 10
Mouse resolution, dpi	1000
Frequency, GHz	2,4
Keyboard dimensions (W × H × L), mm	435 × 18 × 135
Mouse dimensions (W × H × L), mm	59 × 30 × 99
Weight (keyboard + mouse), g	348 and 75

Notes:

- *Technical specifications given in this table are supplemental information and cannot give occasion to claims.*
- *Technical specifications are subject to change without notice due to the improvement of SVEN production.*

Keyboard + Mouse Wireless Combo Set



Model: **Comfort 3300 Wireless**

Импортер в России: ООО «РЕГАРД», 109052, РФ, г. Москва, ул. Нижегородская, д. 86, корп. Б.
Уполномоченная организация в России: ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5. Условия гарантийного обслуживания смотрите в гарантийном талоне или на сайте www.sven.fi.
Гарантийный срок: 12 мес. Срок службы: 2 года.
Производитель: «СВЕН ПТЕ. Лимитед», 176 Джу Чиаг Роуд, № 02-02, Сингапур, 427447.
Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котолахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, № 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

© Registered Trademark of Oy **SVEN**
Scandinavia Ltd. Finland.

SVEN®
YOU WANT – WE CAN

COMFORT 3300
WIRELESS