


**SVEN**®

Portable Speaker System  
with FM-radio

## USER'S MANUAL



**PS-25**

[www.sven.fi](http://www.sven.fi)

***Congratulations on your purchase of the SVEN speaker system!***

**COPYRIGHT**

© 2018. SVEN PTE. LTD. Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

**BUYER RECOMMENDATIONS**

- Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.
- Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

**APPLICATION**

PS-25 multimedia speaker system is designed to play music. There is a built in high-quality broadband speaker, FM-tuner, MP3-player, micro SD memory card slot and USB port for connecting a USB drive.

**PACKAGE CONTENTS**

- Speaker system – 1 pc
- USB to miniUSB power cable – 1 pc
- Carrying strap – 1pc
- Li-Ion battery 18650 (4.2V, 1200mA\*h) – 1 pc
- User's Manual – 1 pc
- Warranty card – 1 pc

**SPECIAL FEATURES**

- LED display
- Headphones jack
- Built-in player with USB flash and with micro SD memory card
- Built-in FM tuner

**Speaker system description**

- ① POWER button (long pressing)
- ② 0-9: numeric pad to enter the station number or track number
- ③ Play/Pause button (in Player mode);  
MUTE (in Radio mode);  
Exit the Time setting mode
- ④ FM: Radio mode selection
- ⑤ M: switching modes button: Radio / Player / Clock (short pressing);  
Repeat mode selection (long pressing in Player mode);  
Start/Stop auto scan (long pressing in Radio mode);  
Enter Time setting mode (long press in the Clock mode)
- ⑥ Display
- ⑦ Previous track (in Player mode);  
Next station (in Radio mode);  
Time setting
- ⑧ Next track (in Player mode);  
Next station (in Radio mode);  
Time setting
- ⑨ TF: micro SD card slot
- ⑩ DC5V: mini USB jack for charger connecting, the USB port of laptop / PC




Fig. 1. Speaker system description

- ⑪ Volume control wheel
- ⑫ USB: USB-flash card slot
- ⑬ Headphones jack

### CONNECTION AND OPERATION

**Attention!** The built-in battery must be charged completely prior to the application.

#### Speaker system battery charging

- Connect speaker system to a USB port of PC or USB charger using miniUSB to USB cable (included). When charging, the battery indicators   flash alternately. When the battery is fully charged, the battery indicator lights up .




Fig. 2. Connection diagram

## OPERATION MODES

### Radio mode

- Turn on the speaker system – press button ⑤ several times until, the radio mode will not turn on. Long-term pressing button ⑤ activates auto search mode. After scanning completion, the first scanned radio station will start to operate automatically. With buttons ⑦ and ⑧ select a desired radio station.

### Player mode

**Attention! The file system of a micro SD carrier is FAT32. Maximum volume is 32 GB. It is not recommended to use the micro SD Ultra Speed.**

- The system will enter the Player mode automatically when a carrier (USB flash or SD card) is connected to corresponding ports. Use button ③ to switch between Play / Pause modes. You can control tracks by using buttons ⑦ (previous track) and ⑧ (next track).

## TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Frequency range, Hz	speaker: 120-20000
Output power (RMS), W:	3
Membrane, mm	Ø 33
Battery capacity, mA * h	1200
Power supply, V	USB/DC5V
Weight, kg	0,12
Dimensions, mm	92 × 56 × 32

### Notes:

- **Technical specifications given in this table are supplemental information and cannot give occasion to claims.**
- **Technical specifications and package contents are subject to change without notice due to the improvement of SVEN production.**

Technical support is on [www.sven.fi](http://www.sven.fi).

## Portable Speaker System with FM-radio

# SVEN®

### Model: **PS-25**

Импортер в России: ООО «РЕГАРД», 105082,  
г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5.  
Уполномоченная организация в России: ООО «РТ-Ф»,  
105082, г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5.

Условия гарантийного обслуживания смотрите  
в гарантийном талоне или на сайте [www.sven.fi](http://www.sven.fi).

Гарантийный срок: 12 мес.

Срок службы: 2 года.

Производитель: «СВЕН ПТЕ. Лимитед»,  
176 Джу Чиат Роуд, № 02-02, Сингапур, 427447.  
Произведено под контролем «Свен Скандинавия

Лимитед», 48310, Финляндия, Котка,  
Котлахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road,  
№ 02-02, Singapore, 427447. Produced under the  
control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie,  
Kotka, Finland, 48310. Made in China.

© Registered Trademark of Oy SVEN  
Scandinavia Ltd. Finland.



# PS-25