

SVEN[®]

Portable Radio

USER MANUAL



SRP-450

www.sven.fi

Congratulations on your purchase of the Sven portable radio!**COPYRIGHT**

© 2020. SVEN PTE. LTD. Version 1.0 (V 1.0).

This manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this manual more exact, some discrepancies may occur. The information in this manual is given on «as is» terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this manual.

BUYER RECOMMENDATIONS

- Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.
- Check up the package contents and availability of the warranty card. Make sure the warranty card has a shop stamp, a legible signature or the seller's stamp and purchase date, and the goods number corresponds to that in the warranty card. Remember: in case of warranty card loss or discrepancy of numbers you forfeit the right for warranty repairs.
- Before installing and using the speaker system, read this manual carefully and keep it for future reference.
- Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

PACKAGE CONTENTS

- Portable radio — 1 pc
- Power cable — 1 pc
- User Manual — 1 pc
- Warranty card — 1 pc

Technical support is on www.sven.fi.

SAFETY PRECAUTIONS

Caution! High voltage inside! To avoid the risk of electric shock do not open or touch elements inside.

- To avoid electric shock, do not open the radio and do not perform repairs by yourself. Service and repairs should be performed only by qualified specialists in an authorized service center. The list of authorized service centers is available on www.sven.fi
- Do not touch the radio power cord plug pins for 2 seconds after unplugging it from the mains.
- Do not put foreign objects inside the holes of the radio.
- Protect the radio from high humidity, water and dust.
- Protect the radio from heating: do not place it closer than 1 m from a heat source. Do not expose it to direct sunlight.
- Do not place any open flame sources on or close to radio.
- Do not place the radio in poorly ventilated areas. Leave an air gap of 10 cm or more. When operating the radio, do not put any devices on it, do not cover it with cloth or other objects preventing it from cooling.
- Do not use any chemical agents for cleaning. Clean it with dry soft cloth only.

SPECIAL FEATURES

- Built-in FM/AM/SW-radio
- Telescopic swivel antenna
- Wired connection

Description

- ① Connector for charging radio from 4.5V charger
- ② AUX: 3.5 mm mini-jack for audio signal connecting (phone, MP3 player, etc.)
- ③ Telescopic swivel antenna
- ④ Battery compartment type D/UM-1 (rear)
- ⑤ Connector for charging radio from mains ~ 230V (rear)
- ⑥ Station tuning knob
- ⑦ Mode select button (FM/AM/SW radio)
- ⑧ Portable radio on/off knob/volume control knob




Fig. 1. Top view




Fig. 2. Front view




Fig. 3. Connection diagram

CONNECTION AND OPERATION

The portable radio SRP-450 can be connected to almost any audio source: MP3, PC sound card, etc. (see connection diagram in figure 3).

- Before connecting, make sure that the device is disconnected from the mains. Connect the portable radio to the audio output of the audio source using the 3.5 mm mini-jack signal cable to the mini-jack (not included) (see connection diagram in figure 3).
- Set the master volume level to minimum by turning knob ⑧ counterclockwise until it stops.
- Connect the power cable to the mains.
- Turn on the audio source.
- Adjust the master volume level by turning the knob ⑨.

Attention! For powering the radio, it is possible to use D/UM-1 batteries (2 pcs.) (not included). Install them into the battery compartment ④. Observe the polarity.

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Frequency range, H	150 – 20 000
Output power (RMS), W	3
Speaker diffuser diameter, mm	Ø 90
Power supply, V	~230V/50Hz,  4.5V, battery, battery type D/UM-1 (1.5V) – 2 pcs.
Rated current (230V), A	0.029
Weight, kg	0.65
Dimensions, mm	210 × 130 × 60

Notes:

- **Technical specifications given in this table are supplemental information and cannot give occasion to claims.**
- **Technical specifications and package contents are subject to change without notice due to the improvement of SVEN production.**

Portable Radio

SVEN®



Model: SRP-450

Импортер в России: ООО «Регард», 105082, г. Москва, ул. Фридриха Энгельса, д.75, стр. 5.
Уполномоченная организация в России: ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха Энгельса, д. 56, стр. 1. Условия гарантийного обслуживания смотрите в гарантийном талоне или на сайте www.sven.fi. Гарантийный срок: 12 мес. Срок службы: 5 лет.
Производитель: «СВЕН ПТЕ. Лимитед», 176 Джу Чиат Роуд, № 02-02, Сингапур, 427447.
Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котлахдентие, 15. Сделано в Китае.

® Registered Trademark of Oy SVEN Scandinavia Ltd. Finland.



SRP-450